




Item #000000
Model #L-GG019PST

USE AND CARE GUIDE

GRILL GAZEBO



Questions, problems, missing parts? Before returning to the store,
call Hampton Bay Customer Service
8 a.m. - 6 p.m., EST, Monday-Friday

1-855-HD-HAMPTON

HAMPTONBAY.COM

THANK YOU

We appreciate the trust and confidence you have placed in Hampton Bay through the purchase of this grill gazebo. We strive to continually create quality products designed to enhance your home. Visit us online to see our full line of products available for your home improvement needs. Thank you for choosing Hampton Bay!

Table of Contents

Table of Contents.....	2	Hardware Included.....	3
Safety Information.....	2	Package Contents	4
Warranty.....	2	Assembly	5-6
What is Covered	2	Care and Cleaning	7
What is Not Covered	2		
Pre-Assembly	3		
Planning Assembly.....	3		

Safety Information

1. Some parts may contain sharp edges. Wear protective gloves.
2. When assembling and using this product, basic safety precautions should always be followed to reduce the risk of personal injury and damage to equipment. Please read all instructions before assembly and usage.



DANGER: This unit is heavy! Do not assemble this item alone.



WARNING: Do not leave the gazebo where there is a risk of high wind, as possible damage will occur to the structure.



CAUTION: Do not climb on top of the gazebo. Falling off the gazebo can result in serious injury, possibly even death.

NOTICE: For outdoor use only.

Warranty

1 YEAR WARRANTY

WHAT IS COVERED

This limited warranty is extended to the original purchaser and applies to defects in materials and workmanship of your item provided the item is maintained with care and used only for personal, residential purposes. The item is warranted to be free from defects in material or workmanship for a period of 1 year.

WHAT IS NOT COVERED

We do not reimburse for transportation of delivery costs, or compensate the individual or any outside party for assembling or disassembling the product.

Contact the Customer Service Team at 1-855-HD-HAMPTON or visit www.Hamptonbay.com.

Pre-Assembly


PLANNING ASSEMBLY

Before beginning assembly of this product, make sure all parts are present. Compare parts with the Hardware Included and Package Contents lists. If any part is missing or damaged, do not attempt to assemble the product. Contact customer service for replacement parts.

HARDWARE INCLUDED





NOTE: Hardware not shown to actual size.



Part	Description	Quantity
AA	M6X20 Bolt	16
BB	M6 Washer	36
CC	M6X40 Bolt	8
DD	M6 Nut	8
EE	M6X20 Bolt	8
FF	Φ5X180MM “7” Shape Stake	12
GG	M6 Wrench	1

Pre-Assembly (continued)

PACKAGE CONTENTS



A1	Pole 1	2
A2	Pole 2	2
B	Long Screen	2
C	Short Screen	2
D	Corner Pole	4
E	Big Center Connector	1
F	Small Center Connector	1
G	Small Top Pole	4
H	Tabletop	2
I	Support bar	4
J	Hook	1
K	Small Canopy	1
L	Big Canopy	1


Installation

1 Attaching the screens to the poles

- Attach the short screen (C) and long screen (B) to pole 1 (A1), pole 2 (A2) and pole 3 (A3) using M6X20 bolts (AA) and M6 washers (BB).



NOTE: To avoid destroying the finish, please handle it with care.




2 Attaching the big center connector

- Put the hook (J) into the big center connector (E). Insert the corner top pole (D) into the big center connector (E).



NOTE: To avoid destroying the finish, please handle it with care.




3 Attaching the corner top pole

- Attach the corner top pole (D) to the top of pole 2 (A2) using M6X40 bolts (CC), M6 washers (BB) and M6 nut (DD).



NOTE: To avoid destroying the finish, please handle it with care.




4 Attaching the small center connector

- Insert the small top poles (G) into the small center connector (F).



NOTE: To avoid destroying the finish, please handle it with care.



Installation


Installation (continued)

5 Attaching the canopy

- Put the big canopy (L) onto the big top. Do not fold. Attach the small top pole (G) to corner top pole (D) using a M6X40 bolt (CC), M6 washer (BB) and M6 nut (DD).



NOTE: To avoid destroying the finish, please handle it with care.




6 Attaching the support bar to the table top

- Attach the support bar (I) to the tabletop (H) using a M6X20 bolt (EE) and M6 washer (BB).




NOTE: To avoid destroying the finish, please handle it with Care.




7 Attaching the table top to the poles

- Attach the tabletop (H) to the poles (A1 and A2) using M6X20 bolts (EE) and M6 washers (BB).



8 Finalizing the assembly

- Secure the other end of the support bar (I) to the poles (A1 and A2), then insert the Pin on the pole into the hole at the end of the support bar (I). Secure the gazebo using the stakes (FF).



Care and Cleaning

- Before using, clean the gazebo completely with a soft dry towel.
- Do not put your gazebo in wet conditions where there is a risk of rust developing.
- When not in use, store in a cool, dry area.



Questions, problems, missing parts? Before returning to the store,
call Hampton Bay Customer Service
8 a.m. - 6 p.m., EST, Monday-Friday

1-855-HD-HAMPTON

HAMPTONBAY.COM

Retain this manual for future use.